



OXVA



Uni Tech 3.0
Nexlim 2
USER MANUAL

PRODUCT STRUCTURE



SPECIFICATIONS

Size:	127.5*28.5*17.5mm
Capacity:	4ml/2ml(TPD)
Screen:	0.85 inch TFT
Output Voltage:	3.2-4.2V
Battery Type:	Built-in 2000mAh
Charging:	Type-C 5V/3A

JUICE FILLING

Fill the e-juice into the cartridge.



TIPS

- After filling the e-juice into a new cartridge, please wait for at least 5-8 minutes before vaping to avoid dry burning.
- After filling the juice, please close as soon as possible to avoid leaking.

INSTRUCTIONS

- Turn on/off:
Press the button 5 times to turn it on/off.
- Vaping:
While the device is on, draw to vape. The device will stop working when the vaping is longer than 8s due to safety protection.

- English - 1 -

- Adjust Mode:
Press the button 2 times to adjust your preferred mode.
- Adjust Output:
Press the button 3 times to adjust your preferred wattage.
- Adjust Theme:
Press the button 4 times select the theme. Click the button 1 time to lock your preferred theme.
- Vaping Animation
Press the button 6 times to turn on/off the Vaping Animation.
- Reset Puffs:
Press the button 7 times to reset the puff count.
- Screen Prompts

BATTERY LOW:	Low Battery
NO POD:	The cartridge is not detected.
SHORT:	Short Circuit
TIMEOUT:	The vaping time is over 8s.
TEMP HIGH:	The temperature of PCBA is too high.

- E-manual:
Long press to read the operation guidance.

ATTENTION

- Please keep away from inflammable and explosive materials to avoid injury.
- Please don't leave the device unattended while charging.
- Please use OXVA brand components and accessories to avoid device damage or health problems.

- English - 2 -

WARRANTY POLICY

Thank you for purchasing OXVA products. OXVA will fulfill the following terms and conditions in order to offer the original buyer with repair or replacement under warranty:

- The warranty covers defects in materials or workmanship under normal use for 90 days from the purchase date. The warranty covers the repair or replacement of any damaged parts.
- This warranty may be disqualified as a result of the following circumstances:
 - The customer does not give this warranty card or the original receipt for purchase.
 - Merchandise failure or damage is caused by improper use or unauthorized adjustments.
 - Merchandise failure or damage caused by extreme force or impact, as well as operating conditions that are not recommended. See the user handbook for details.
 - Merchandise failure or damage caused by exposure to water or other conducting liquids.
 - Merchandise failure or damage caused by using non-OXVA brand accessories.
- This warranty does not cover personal or consumable items like coil heads, USB cables, and mouthpieces.

For more information please visit our website at www.oxva.com
Or email us at support@oxva.com

PURCHASE INFORMATION

Product Model: _____

Date of Purchase (Based on the date from receipt of purchase): _____

Day: _____

Month: _____

Year: _____

Store Information:

Store Name: _____

Phone: _____

Store Address: _____

City: _____

Country: _____

Post Code: _____

Customer Information:

Customer Name: _____

Phone: _____

Customer Address:

City: _____

Country: _____

Post Code: _____

* Please use OXVA brand components and accessories to avoid damage of device or health problems.

Shenzhen Future Tech Co., Ltd
Tel: 0086-755-23315089
Email: support@oxva.com
Web: www.oxva.com
Addr: #601, #B01, Block 1 of WAN TING BLDG, Baoyuan RD, Xixiang Street, Bao'an, Shenzhen, China.



Scan to Discover OXVA

