

## SAFETY WARNINGS


- Warning for vulnerable consumer groups:** This product is not recommended for minors, pregnant or breastfeeding women, or anyone at risk of heart disease, depression, and asthma.
- Battery Caution:** Do not expose the device to extreme temperatures. Do not disassemble the device without Lost Vape's recommendation.
- Pod Cartridge Attention:** Do not dry burn the tank or coil. It is essential to prime a new coil. Simply fill your tank with e-liquid and leave it to stand for at least 5 minutes before vaping. As above, this will allow the cotton inside your new coil to absorb plenty of e-liquid ready for that first, tasty vape. All cartridges/coils are not covered under warranty once they are opened, used, or filled with liquids.
- Warranty:** The device is covered by a 3-month warranty from the date of purchase.
- Contacts:** For further questions or inquiries, please contact Lost Vape by email at support@lostvape.com or visit our website: www.lostvape.com.

## PRODUCT DESCRIPTION


### BASIC PARAMETERS

|                  |                            |
|------------------|----------------------------|
| Dimension        | 20.4*32.4*101.7mm          |
| Net Weight       | 73.0g±3g                   |
| Pod Capacity     | 2.5ml/2ml                  |
| Battery Capacity | 1200mAh                    |
| Battery Voltage  | 3.3V-4.2V                  |
| Power Range      | 5W-35W                     |
| Charging Voltage | 5V/1A                      |
| Type-C Cable     | Support 5V/2A Charger      |
| Body Material    | Aluminum alloy, Plastic PC |

### Snap-on the Cap




1. Cover on the top of the cartridge for anti-dust.




2. Snap-onto the bottom during vaping.

### COMPONENTS OVERVIEW




## BASIC OPERATION

### 3 STEPS TO FILL WITH E-LIQUID



1. Open the silicone tab.



2. Fill with e-liquid.




3. Close the tab.



\*Prime new cartridge by soaking in e-liquid for 5 minutes before vaping.

### Button Operation



### Activation

Press and hold the button when the device is on, or simply draw from the drip tip.

**Note:** Do not press and hold the button when not vaping or when the cartridge is empty, as it will burn the coil.

### Single Mesh Cartridge & Dual Mesh Cartridge

- The Single Mesh Cartridge displays the updated resistance value when connected and shows the recommended power automatically.
- The Dual Mesh Cartridge, upon connection, defaults to dual-coil mode. Double-click the fire button to switch between single and dual modes. The screen will display "S" for single mode or "D" for dual mode.



### Airflow adjustment


Slide the air adjustment button to find the airflow that suits you best. If the auto-draw feels weak, shorten the airflow inlet. If the vapor is too hot, lengthen the airflow inlet.

### Adjust Wattage

- Press the Fire button 3 times consistently within 2 seconds to adjust wattage.
- Short press the Fire button to increment/decrease power by 1W step; long press for rapid incrementation/decrement. Different coil resistance  $\Omega$  has different max./min. power limit. When it reaches the max. power limit, it will prompt "Max Power", stop pressing the button to retain at max. power value. Short press the button again to return to min. power value.

### CHARGING MODE

When the battery is charging, the screen will display the charging status and battery level as follows:



### PUFF TIME DISPLAY & PUFF COUNT RESET

- Effective Puff time reaches 0.5s start counting. And the peak display of puff count is 999.
- The puff count will reset on the next startup.



## WARNING DESCRIPTION

**Low Battery:** The interface will pop-up "Low Battery" and output will automatically cut off once the battery voltage below 3.3V before use or lower than 2.85V when you are using.

**Check Atomizer:** The interface will pop-up "Check Atomizer" when there is no atomizer detected.

**Short Circuit:** The interface will pop-up "Short Circuit" and output will automatically cut off.

**Over 8s:** Output will automatically cut off and the interface will pop-up "Over 8s" when you vape over 8s continuously.