


Drip Tip
Top Cap
Glass Tube
Fire & Revolve Button
Display Screen
Light



Airflow Adjustment
Base
Toggle Switch
Battery Cover
Type-C Port

1

Thanks for your purchase of a VOOPOO product. For the better use of all the functions of this product, please carefully read the operation notes and detailed functional instructions before your first use of this product. If you have any problem with using this product, please contact our local agent or visit our official website at www.voofoo.com

Parameters

Size: 95*45*29 mm (MOD)
Battery: 18650*2 (Not included)
Max Output Voltage: 8.4 V
Power Range: 5-220 W
Charging Voltage: 5 V / 3 A
Resistance Range: 0.05-3.0 Ω
E-liquid Capacity: 5.5 mL (Standard & US Version) / 2 mL (TPD Version)
Included Coils: PnP X 0.15 Ω + PnP X 0.3 Ω

Steps

Step 1: Install the coil

Unscrew the base and insert the coil from the bottom of the tank.

Step 2: Fill the atomizer with e-liquid

Push the top cap, then fill the e-liquid from the filling port. It is recommended to keep the tank two-thirds full.

Step 3: Start to use the device

Let the coil become fully saturated for about five minutes before use. After that, you can adjust the airflow and power to enjoy an optimal vaping experience.



2

Interface Introduction




1. Turn on/off the device: Press the fire button five times quickly.
2. Lock/Unlock power: Push the button up to unlock, and push the button down to lock.
3. Power adjustment: Use the toggle switch to adjust the power. Turn the knob clockwise to increase the power and counterclockwise to decrease the power.
4. MENU: Press the fire button three times quickly to enter the menu.
5. Mode: After entering the setting interface, select the "Mode" option, then choose the mode of the device on the sub-interface.


- SMART: This mode can identify the best power and prevent the coil from burning due to excessive power during use.
- RBA: User-customizable power adjustment from 5 W to 220 W.
- TC-TCR:
 - A) Support four kinds of heating wire: Ni200, Titanium (Ti), SS316, and SS430.
 - B) TC adjustable range: 200-600 $^{\circ}$ F / 100-315 $^{\circ}$ C.

3

- A) Support four kinds of heating wire: Ni200, Titanium (Ti), SS316, and SS430.
 - B) TC adjustable range: 200-600 $^{\circ}$ F / 100-315 $^{\circ}$ C.
 - C) In TC mode, press the fire button twice consecutively to switch between $^{\circ}$ C and $^{\circ}$ F.
 - D) Recommended resistance value range for TC mode: 0.05 Ω -3.0 Ω .
6. THEME: Choose the User Interface (UI) theme.
 7. SWITCH: After entering the setting interface, select the "Switch" option, then choose the function of the switch in the sub-interface: "Lock/Unlock the device" or "Lock/Unlock the power".
 8. ANIMATION: Users can choose whether they want a flame vaping animation.
 9. LIGHT: Users can choose whether they need a light display.
 10. PUFF CLEAN: Puff data will be cleared.
 11. BATTERY EVALUATION: Check the health of both batteries.
 12. ABOUT DEVICE: Displays the software version number of the current host.
 13. EXIT: Exit the main menu.
 14. Charging: Support charging with 5 V / 3 A. It is recommended to use the Type-C cable provided by VOOPOO to charge the device.
 15. Software upgrade: Consumers can upgrade the software to the latest version via VOOPOO's official website (www.voofoo.com), which requires a specific Type-C cable to connect the VOOPOO product to the computer. Please keep your device fully charged.
 16. Status notification




4



Battery Installation

1. Open the battery cover.
2. Install the 18650 battery from the bottom, ensuring correct polarity according to the electrode markings. (It is recommended to use a high-rate battery with a discharge current of \geq 30A.)
3. Reattach the battery cover.



Notes

1. This product is not recommended for minors, non-smokers, pregnant or breast-feeding women, or anyone at risk of heart disease, depression, or asthma.
2. Please keep the device away from heat, fire and water. This device should be stored in a cool and shady environment.
3. Please do not drop, throw or immerse the device in the water.
4. Please turn off or lock the device to avoid accidental firing when you carry it out.
5. Please rationally use the device according to your personal situation. If discomfort occurs, please stop using it immediately.
6. EEE Recycling: This product should not be treated as household waste. Instead it should be taken to the collection place for the recycling of electrical and electronic equipment.

5

7. Battery Recycling: The product battery should not be treated as household waste. Instead it should be taken to the used battery collection place for recycling.
8. It is recommended to use the Type-C cable provided by VOOPOO to charge the device.
9. During the long-term unused period of the device, it is recommended to charge regularly to prevent discharge!
10. The storage period of the equipment shall be within 3 months. The ambient temperature ranges from -5 $^{\circ}$ C-30 $^{\circ}$ C, with humidity 25% \pm 75% RH. Operating temperature of the electronic cigarette: 0 $^{\circ}$ C-40 $^{\circ}$ C!
11. Disassembly is prohibited after product failure!
12. Only for indoor charging, please use a UL-certified USB charger to avoid the danger of fire and explosion!

Warm Prompt

Atomizer Leakage
There is a possibility of e-liquid leakage at high pressure when you travel by air. Therefore, please keep your device away from other important objects.
Deal with Condensate
There may be slight condensation due to the difference between indoor and outdoor temperature when you use the device. It is advisable to take out the atomizer, and shake it downwards.



6