LOST VAPE

LOST VAPE

THELEMA SQUB POD BOX MOD

www.lostvape.com

lost-vape@aspatech

SAFETY WARNINGS

Thank you for purchasing this product. This product is intended for adult vapers who are familiar with the operation of a vape product. Please read this manual carefully before using the product.

Battery Caution:
Improper battery use or battery damage can occasionally cause battery explosion, fire and other dangers.
Do not disassemble, short circuit, crush, puncture, or place in a high temperature environment.
Do not expose the device to extreme temperatures.
Do not charge batteries unattended.
Do not use damaged batteries or chargers.

Coil Warning:
Improper coil use or coil damage can occasionally cause leakage, fire and other dangers.
Please use the coil in accordance with the instructions and do not short circuit the coil.
Do not expose the device to extreme temperatures.
Do not use damaged coils.

Liquid Warning:
Improper liquid use can occasionally cause leakage, fire and other dangers.
Please use the liquid in accordance with the instructions and keep it out of the reach of children and pets.
Do not expose the liquid to extreme temperatures.
Do not use damaged or expired liquids.

Cleaning:
Please use a dry cloth to clean the device and avoid contact with liquids.

Warning:
Do not use this product if you are pregnant or breastfeeding, have a medical condition, or are under the influence of alcohol, medication, or drugs.
Do not use this product while driving or operating machinery.
Do not use this product in a hot tub, sauna, or other high temperature environment.
Do not use this product in a place where smoking is prohibited.
Do not use this product if you are allergic to any of its components.
Do not use this product if you are under 18 years old.
Do not use this product if you are a non-smoker.
Do not use this product if you are a pacemaker or other medical device user.
Do not use this product if you are a diabetic.
Do not use this product if you are a person with a cardiovascular disease.
Do not use this product if you are a person with a respiratory disease.
Do not use this product if you are a person with a mental illness.
Do not use this product if you are a person with a history of drug addiction.
Do not use this product if you are a person with a history of alcohol addiction.
Do not use this product if you are a person with a history of smoking addiction.
Do not use this product if you are a person with a history of addiction to other substances.
Do not use this product if you are a person with a history of addiction to other products.
Do not use this product if you are a person with a history of addiction to other products.

COMPONENTS OVERVIEW

Front Panel — Screen — Fire Button — Type-C Port — Battery Cover — Magnetic Suction Cover

BASIC OPERATION

INSTALL BATTERY
Open the battery cover, insert the battery, and close the battery cover.

TURN ON/TURN OFF
Quickly press the fire button 5 times to turn the device on/off.

FUNCTION OPERATION
Quickly press the fire button 3 times to enter the function menu, press the fire button 3 times to select a function, hold the fire button and press the fire button 3 times to exit the function menu.

BASIC PARAMETERS

Dimensions	28.5*23.5*84.5mm
Weight	100g
Battery	1*18650 (Not Included)
Battery Voltage	3.0V-4.2V
Battery Capacity	1500mAh
Charging Voltage	5V
Charging Current	1A
Charging Port	Type-C
Screen	0.96 inch Color Screen
Screen Brightness	3 Levels Adjustable
Screen Rotation	Automatic Rotation
Screen Protection	Screen Lock Function
Screen Display	Battery Percentage, Puff Count, Puff Time, Resistance, Voltage
Protection	Short Circuit Protection, Low Voltage Protection, Overheat Protection, Overcharge Protection, Overcurrent Protection, Overvoltage Protection, Overdischarge Protection

UI DISPLAY CHANGES

Screen Off — Screen Lit — Full Power — Resistance — Voltage — Puff Count — Puff Time — Voltage

The UI display shown here is for reference only.

SERVICE MODE SWITCH

Quickly press the fire button 3 times to enter the function menu, press the fire button 3 times to select the service mode, hold the fire button and press the fire button 3 times to exit the function menu.

Service Mode:
Quickly press the fire button 5 times to turn on the device, and the screen will display "SERVICE MODE" for 3 seconds. In this mode, the device will not record puff count or puff time, and the screen will not display puff count or puff time.

Factory Reset:
Quickly press the fire button 5 times to turn on the device, and the screen will display "FACTORY RESET" for 3 seconds. In this mode, the device will reset all parameters to factory settings.

Screen Rotation:
Quickly press the fire button 5 times to turn on the device, and the screen will display "SCREEN ROTATION" for 3 seconds. In this mode, the screen will rotate 180 degrees.

Screen Lock:
Quickly press the fire button 5 times to turn on the device, and the screen will display "SCREEN LOCK" for 3 seconds. In this mode, the screen will be locked and cannot be operated.

Screen Protection:
Quickly press the fire button 5 times to turn on the device, and the screen will display "SCREEN PROTECTION" for 3 seconds. In this mode, the screen will be protected and cannot be operated.

Screen Display:
Quickly press the fire button 5 times to turn on the device, and the screen will display "SCREEN DISPLAY" for 3 seconds. In this mode, the screen will display battery percentage, puff count, puff time, resistance, voltage.

Screen Brightness:
Quickly press the fire button 5 times to turn on the device, and the screen will display "SCREEN BRIGHTNESS" for 3 seconds. In this mode, the screen will adjust brightness.

Screen Rotation Sensitivity:
Quickly press the fire button 5 times to turn on the device, and the screen will display "SCREEN ROTATION SENSITIVITY" for 3 seconds. In this mode, the screen will adjust rotation sensitivity.

Screen Lock Time:
Quickly press the fire button 5 times to turn on the device, and the screen will display "SCREEN LOCK TIME" for 3 seconds. In this mode, the screen will adjust lock time.

Screen Protection Time:
Quickly press the fire button 5 times to turn on the device, and the screen will display "SCREEN PROTECTION TIME" for 3 seconds. In this mode, the screen will adjust protection time.

Screen Display Time:
Quickly press the fire button 5 times to turn on the device, and the screen will display "SCREEN DISPLAY TIME" for 3 seconds. In this mode, the screen will adjust display time.

Screen Brightness Sensitivity:
Quickly press the fire button 5 times to turn on the device, and the screen will display "SCREEN BRIGHTNESS SENSITIVITY" for 3 seconds. In this mode, the screen will adjust brightness sensitivity.

Screen Lock Sensitivity:
Quickly press the fire button 5 times to turn on the device, and the screen will display "SCREEN LOCK SENSITIVITY" for 3 seconds. In this mode, the screen will adjust lock sensitivity.

Screen Protection Sensitivity:
Quickly press the fire button 5 times to turn on the device, and the screen will display "SCREEN PROTECTION SENSITIVITY" for 3 seconds. In this mode, the screen will adjust protection sensitivity.

Screen Display Sensitivity:
Quickly press the fire button 5 times to turn on the device, and the screen will display "SCREEN DISPLAY SENSITIVITY" for 3 seconds. In this mode, the screen will adjust display sensitivity.

CAUTIONS

Do not use the device in a place where smoking is prohibited.
Do not use the device in a place where there is a risk of fire.
Do not use the device in a place where there is a risk of explosion.
Do not use the device in a place where there is a risk of electric shock.
Do not use the device in a place where there is a risk of injury.
Do not use the device in a place where there is a risk of damage to the device.
Do not use the device in a place where there is a risk of damage to the environment.
Do not use the device in a place where there is a risk of damage to the environment.

PRÉCAUTIONS RÉGLEMENTAIRES

Avertissement :
Veuillez lire attentivement le manuel avant utilisation.
Ne pas utiliser le produit si vous êtes enceinte, allaitez, souffrez d'une maladie, êtes sous l'influence de l'alcool, de médicaments ou de drogues.
Ne pas utiliser le produit en conduisant ou en utilisant des machines.
Ne pas utiliser le produit dans un bain chaud, un sauna ou tout autre environnement à haute température.
Ne pas utiliser le produit dans un lieu où fumer est interdit.
Ne pas utiliser le produit si vous êtes allergique à l'un de ses composants.
Ne pas utiliser le produit si vous êtes mineur.
Ne pas utiliser le produit si vous êtes non-fumeur.
Ne pas utiliser le produit si vous êtes porteur d'un stimulateur cardiaque ou d'un autre dispositif médical.
Ne pas utiliser le produit si vous êtes diabétique.
Ne pas utiliser le produit si vous êtes une personne souffrant de maladie cardiovasculaire.
Ne pas utiliser le produit si vous êtes une personne souffrant de maladie respiratoire.
Ne pas utiliser le produit si vous êtes une personne souffrant de maladie mentale.
Ne pas utiliser le produit si vous êtes une personne ayant un antécédent de toxicomanie.
Ne pas utiliser le produit si vous êtes une personne ayant un antécédent d'alcoolisme.
Ne pas utiliser le produit si vous êtes une personne ayant un antécédent de tabagisme.
Ne pas utiliser le produit si vous êtes une personne ayant un antécédent d'addiction à d'autres substances.
Ne pas utiliser le produit si vous êtes une personne ayant un antécédent d'addiction à d'autres produits.
Ne pas utiliser le produit si vous êtes une personne ayant un antécédent d'addiction à d'autres produits.

COMPOSANTS DU PRODUIT

Panneau avant — Écran — Bouton de tir — Port Type-C — Couvercle de batterie — Couvercle aimanté

FONCTIONNEMENT DE BASE

INSTALLER LA BATTERIE
Ouvrir le couvercle de batterie, insérer la batterie et fermer le couvercle de batterie.

ALLUMER/ÉTEINDRE
Appuyer rapidement sur le bouton de tir 5 fois pour allumer/éteindre l'appareil.

FONCTIONNEMENT
Appuyer rapidement sur le bouton de tir 3 fois pour accéder au menu des fonctions, appuyer sur le bouton de tir 3 fois pour sélectionner une fonction, maintenir le bouton de tir et appuyer sur le bouton de tir 3 fois pour quitter le menu des fonctions.

PARAMÈTRES BASIQUES

Dimensions	28.5*23.5*84.5mm
Poids	100g
Batterie	1*18650 (Non incluse)
Tension de batterie	3.0V-4.2V
Capacité de batterie	1500mAh
Tension de charge	5V
Courant de charge	1A
Port de charge	Type-C
Écran	Écran couleur 0.96 pouce
Luminosité de l'écran	3 niveaux réglables
Rotation de l'écran	Rotation automatique
Protection d'écran	Fonction verrouillage d'écran
Affichage d'écran	Pourcentage de batterie, nombre de bouffées, durée de bouffée, résistance, tension
Protection	Protection contre les courts-circuits, protection contre la tension faible, protection contre la surchauffe, protection contre la surcharge, protection contre la surintensité, protection contre la surtension, protection contre la décharge excessive

MODIFICATIONS DE L'INTERFACE

Écran éteint — Écran allumé — Pleine puissance — Résistance — Tension — Nombre de bouffées — Durée de bouffée — Tension

L'interface de l'écran ci-dessus est uniquement à titre de référence.

ÄNDERUNGEN DER BEDIENOBERFLÄCHE

Bildschirm aus — Bildschirm an — Vollleistung — Widerstand — Spannung — Anzahl der Züge — Zugdauer — Spannung

*Die hier gezeigte Bildschirmoberfläche dient nur zur Orientierung